

# Create Your Own



## PhoTote

### PhoTote Materials List

Amazing GOOP® Household  
with snip tip  
(3) QuickFuse™ Fusible Inkjet  
Fabric Sheets - White  
11" Pastel Canvas Tote  
Simple Stitch 1/2" spool,  
Black ribbed w/White stitch  
Zucker Feather Products  
Marabou Craft Boa - 6' Black

It's So Me Beaded Fringe 36" Hot Pink  
Crafting Expressions 30SS  
Acrylic Rhinestone - Crystal 110 pcs  
**Other Supplies:**  
Wax paper (protect work area)  
Scissors  
Pencil  
Ruler  
Cracker box or likeness

Designed by Michele Nored for Eclectic Products, Inc.



Items for the PhoTote

#1 GOOP handle

#2 Adhere fringe

#3 Adhere boa

#4 - #5 Photo & Rhinestones

Completed Photote

### Directions

Note: Read these directions and the instructions on the opposite side completely before beginning this project.

Always work on a level and protected surface. Wax paper works great to protect work area. Use photos as a guide.

Household GOOP® is machine washable; however the boa and fringe used in this project are not.

- #1 Beginning just below handle, apply a bead of GOOP, continue down center of handle & end on the other side just below handle. Center & press ribbon firmly to handle. Trim excess ribbon. Turn tote over & repeat on opposite handle.
- #2 Apply GOOP directly to outer rim of tote along stitching or about 1" from top. Press fringe firmly to GOOP. Turn tote over & repeat on other side. Overlap fringe about 1/4", apply a dab of GOOP & press firmly together. Trim excess fringe.  
Next, apply GOOP directly to outer rim above fringe. Press boa firmly to GOOP. Turn tote over & repeat on other side. Overlap boa about 1/4", apply a dab of GOOP & press firmly together. Trim excess boa.

- #3 Insert cracker box or likeness to hold corners of base open. With tote standing up, adhere boa around base of tote.  
Following manufacturers directions, print, trim, center & iron your desired photograph (approximately 4'x6') onto tote between top fringe & bottom boa.
- #4 Outline photo with ribbon: Working one side at a time, apply a bead of GOOP along photo's edge. Press ribbon firmly to GOOP. Trim excess ribbon in corners at an angle. Make sure corners are secured.
- #5 Adhere rhinestones to ribbon: Starting in the corners, then in the center, then in between corner & center, apply a small dab of GOOP to ribbon & press rhinestones firmly to GOOP. Adhere rhinestones to ribbon on handles also.
- #6 Project complete and ready to use in approximately 24-72 hours.

Revised: 10/03/06 for Web Site/Eclectic Products, Inc. - All Rights Reserved.



Household ADHESIVE

## INSTRUCTIONS

1. Surface should be clean, dry and free of dirt. For best results, roughen surface before use. Use GOOP in a well-ventilated area.
2. Puncture the seal in the neck of the tube using the pointer cap. Product can be used between 50°F (10°C) and 90°F (32°C). Dry time decreases when used between 70°F (21°C) and 90°F (32°C).
3. Always test a small area to ensure proper application techniques and dry time.
4. Apply GOOP directly to each surface to be bonded or repaired. Allow GOOP to partially cure, 2-10 minutes before bringing surfaces together.
5. Allow the repair to dry for 24 hours. Depending on the materials and temperature, maximum strength may not be reached for 48 to 72 hours.
6. To ensure easy cap removal, apply a thin coat of petroleum jelly to the threads of the tube before replacing the cap.
7. Clean uncured adhesive with acetone or naphtha, the adhesive will ball up and brush off. Cured material may be removed by cutting or scraping.
8. For further information, call (800) 767-4667.

**Note:** GOOP may damage finished surfaces. Avoid such contact until GOOP is completely dry. GOOP is not recommended for any items that come into contact with food, drinking water or animals. Do NOT dry-clean GOOP because dry cleaning solvent breaks down the cured adhesive. GOOP is not recommended for use on polystyrene, polyethylene or polypropylene plastics. Do not use GOOP for bonding Styrofoam™ or paper products.

## COMMONLY ASKED QUESTIONS

### What temperature range does GOOP withstand?

GOOP can be applied in temperatures ranging from 50°F to 90°F. When cured, GOOP can withstand temperatures between -40°F and 150°F.

### How can uncured GOOP be cleaned up?

Small amounts of acetone or citrus-based solvents may be used. GOOP will ball up and brush off.

### How can cured GOOP be removed?

Cured GOOP may be removed by cutting or scraping.

### How long does GOOP take to dry?

A full cure takes 24 to 72 hours, depending on the surrounding environment. Cure time increases with lower temperatures and decreases with high temperatures.

### How can dry time be decreased?

To speed drying time, apply heat using a hand-held hair dryer. Set dryer on low and do not hold directly on GOOP.

### Can GOOP be dry-cleaned?

No. Dry-cleaning solvent breaks down GOOP. GOOP is washer/dryer safe.

### Can GOOP be used on Styrofoam™ ?

No. GOOP is not recommended for use on any *polystyrene*, *polyethylene* or *polypropylene* plastics.

### What materials will GOOP adhere to?

GOOP works on virtually any material, including glass, plastic, metal, leather, vinyl, rubber, neoprene, poly carbonate, brick, marble, ABS, PVC, copper, waterproof cloth, aluminum, brass, wood, linoleum, fiberglass, Naugahyde™, porcelain and ceramic.

**CAUTION - Flammable, Vapor Harmful:** Contains toluene and petroleum distillate. May cause dizziness, headache or nausea. Causes eye, skin, nose and throat irritation. Intentional misuse by deliberately concentrating and inhaling the contents may be harmful.

**WARNING:** This product contains a chemical known to the state of California to birth defects or other reproductive harm.

Keep away from heat and flame. Extinguish all sources of ignition during and until all vapors are gone. Prevent build-up of vapors by opening all window and doors to achieve cross ventilation.

**Use only with adequate ventilation.** To avoid breathing vapor, open all windows and doors to assure fresh air movement during application and drying. Close container after use. Avoid contact with eyes and skin. Wash thoroughly after handling.

**FIRST AID:** If you experience difficulty in breathing, leave the area to obtain fresh air. If continued difficulty is experienced, get medical assistance immediately. In case of eye contact, flush immediately with plenty of water and get medical attention; for skin wash thoroughly with soap and water. If swallowed, do not induce vomiting, get medical attention.

### KEEP OUT OF THE REACH OF CHILDREN.

**LIMITED WARRANTY:** The manufacturer will not accept liability for more than product replacement.

www.amazinggoop.com Made in the U.S.A. by Eclectic Products, Inc. - - - Pineville LA 71361

05/06